



## INSTALLING DESTROKED MOTOR MOUNTS

This document is a guide to help you install your Destroyed Motor Mount Kit. Positioning of the mounting brackets are key to an easy install so double check the placement!

### STEP ONE:

Place the motor mount brackets on the frame of the vehicle. Make sure that the cut outs are facing the correct direction, wider tabs are on the top of the brackets. See pic 01 photo taken facing the front of the vehicle.



### CLOSE UPS:

Check out Pic 2 this is a photo of the passenger side mount installed. Pic 3 is the drivers side bracket installed. Double check the bracket shape to these photos when installing the brackets, you'll be glad that you did!



## STEP TWO:

Installing the motor mounts on the engine are pretty straight forward but check the photos out anyway! You also want to make sure that the motor mount bolts are torqued to 95 N·m (70 ft. lbs.) torque. Check out the photos below. Pic 4 shows the mount in place on the drivers side (note position the ECM) Pic 5 shows the mount in place on the passengers side (oil filter would up and to the right of the mount in this photo)



## FINAL THOUGHTS AND INFO:

We have also included a couple reference photos (pics 6 and 7) so you can see how the motor mount and the mounting brackets fit together when installed.

Photo 6 shows the driver's side bracket/mount assembly looking from the front of the vehicle back towards the transmission.

Photo 7 shows the passenger side bracket/mount assembly looking forward towards the radiator. On Both mounts, make sure that the cut-outs are facing the correct direction.

If you have any questions on installation, or have comments on how to improve these installation instructions, please contact Destroked at: **303-945-7570**

